

# VULCAN DRIFTER RIDERS



[HOME](#) | [FORUM](#)

## Indian Headlight Conversion

### INDIAN TEARDROP HEADLIGHT CONVERSION *For Dummies*

#### REQUIRED PARTS:

Complete Indian or Rick Doss  
Headlight Nacelle



HD Road King Risers  
Standard to Metric  
Studs, Nuts & Washers

Two - 2.5"  
Hanging  
Clamps

Four - 3/8  
1 3/4"  
Set- Screws

Eight - Nuts  
Eight - Washers  
Four - Chrome  
Acorn Nuts



#### PROCEDURE:



1. Remove & tap the top tripletree - 3/8"  
*Take your time DO NOT screw this up*
2. Re-attach tripletree, risers & handlebars
3. Attach clamps just above bottom tripletree.  
Insert set-screws into clamps & top tripletree  
*(do not overtighten or use thread-lock yet)*
4. Attach nacelle one side at a time. Adjust  
clamps until everything lines up.
5. Mark where you will need to grind the  
housing (see page two)
6. Grind. Jigsaw worked well for me
7. Tighten clamps, thread-lock set-screws &  
tighten for good
8. Reassemble the housing & instal headlight  
for good or see options below



**OPTIONS:** Leave Chrome, Paint or Powdercoat as You See Fit.  
Add Indian Windshield and Lightbar with Harley Lights for Full Effect ▼



© Saftek Inc. 2015

**GET ANY INTERNET  
THEN ADD PHONE & TV**

*Not affiliated with Kawasaki. Kawasaki, Vulcan and Drifter are trademarks of Kawasaki.*